

Oven Thermometers

easy to read bi-metal

Ø50 mm dial oven thermometer



This stainless steel oven thermometer features a clear Ø50 mm dial with colour-coded zones. The green marker indicates the minimum temperature that commercial heated display units should be kept at. The oven thermometer indicates temperature over the range of 50 to 300 °C in 10 °C divisions. The case measures 40 x 60 x 70 mm.

The unit can be free-standing or hung from a shelf and should be positioned in the middle of the oven for the most accurate temperature reading.

order code	description
800-931	Ø50 mm dial oven thermometer

Ø55 mm dial oven thermometer



This stainless steel oven thermometer features a clear Ø55 mm dial with colour-coded zones. The green marker indicates the minimum temperature that commercial hot food display units should be kept at. The oven thermometer indicates temperature over the range of 0 to 300 °C in 10 °C divisions. The case measures 43 x 66 x 80 mm.

The thermometer can be free-standing or hung from a shelf and should be positioned in the middle of the oven for the most accurate temperature reading.

order code	description
800-809	Ø55 mm dial oven thermometer

Digital Timer

oven & cooking thermometer

This combined clock, countdown timer and thermometer displays both the actual and the alarm temperature over the range of 0 to 300 °C and simultaneously the countdown or the actual time.

The timer will count down or up from/to 23 hours, 59 minutes and 59 seconds and the real time clock will display the time in either a 12 or 24 hour format.

The unit features an audible high alarm that can be set from the simple to use seven-button keypad. The alarm temperature is continuously displayed. The unit is designed to sit on a worktop or can be attached to an appliance via the magnetic pads at the rear of the instrument.

The thermometer is supplied with a high temperature probe and a one metre stainless steel braided lead. The probe has an insertion length of 150 mm (Ø4mm) incorporating a reduced diameter tip for faster response.

order code	description
810-060	oven thermometer & timer
810-061	replacement probe



specification	oven thermometer & timer
range	0 to 300 °C
resolution	1 °C/°F
accuracy	±1 °C (0 to 130 °C)
battery & life	2 x 1.5 volt AAA - 5000 hours
sensor type	thermistor
display	triple custom LCD
dimensions	18 x 73 x 125 mm
weight	128 grams