

Multi-Function Thermometer

with max/min & alarm functions

- displays both temperature & alarm set temperatures
- includes CalCheck 0.0 °C function

The Multi-Function is a compact and easy to use thermometer ideal for restaurants, bars and cafes as an economical solution for temperature measurement applications.

The thermometer features a display hold facility, max/min memory and a CalCheck 0.0 °C function together with an adjustable audible high/low temperature alarm.

The Multi-Function thermometer housing and probe handle now includes 'Biomaster' additive that reduces bacterial growth. Each unit is supplied with a stainless steel, food penetration probe (Ø3.5 x 125 mm) with one metre PVC connecting lead, pocket clip and probe cover.



order code	description
810-961	Multi-Function thermometer - white
810-964	Multi-Function thermometer - red
810-965	Multi-Function thermometer - blue



specification	Multi-Function
range	-49.9 to 149.9 °C
resolution	0.1 °C/°F
accuracy	±1 °C (-19.9 to 149.9 °C)
battery & life	1.5 volt AAA - 5000 hours
sensor type	thermistor
display	custom LCD
dimensions	25 x 85 x 116 mm
weight	98 grams

EcoTemp® Thermometer

with max/min & hold functions

- detachable, stainless steel food penetration probe
- 'Biomaster' anti-bacterial additive

The EcoTemp digital thermometer features a large, easy to read, LCD display with display hold and max/min memory functions. The instrument measures temperature over the range of -49.9 to 199.9 °C with a 0.1 °C/°F resolution. Both open circuit and low battery indication are displayed, when applicable. This thermometer is ideal for monitoring cooking and food holding temperatures as part of HACCP and health and safety procedures.

The EcoTemp thermometer housing and probe handle now includes 'Biomaster' additive that reduces bacterial growth. Each unit is supplied with a detachable, stainless steel food penetration probe (Ø3.5 x 125 mm) with a 700 mm silicone connecting lead.



order code	description
810-950	EcoTemp thermometer & probe
810-951	replacement penetration probe
830-215	protective silicone boot - white



specification	EcoTemp
range	-49.9 to 199.9 °C
resolution	0.1 °C/°F
accuracy	±1 °C (-49.9 to 149.9 °C)
battery & life	2 x 1.5 volt AAA - 10000 hours
sensor type	thermistor
display	custom 22 mm LCD
dimensions	20 x 58 x 165 mm
weight	115 grams