

CHEFALARM® THERMOMETER & TIMER

- Interchangeable NTC thermistor probes
- Programmable high/low alarm

The ChefAlarm is a professional cooking thermometer and timer which displays the countdown/up time, current temperature and simultaneously displays both the high/low alarms and max/min temperatures.

The timer is fully programmable, allowing the user to set the countdown/up time to/from 99 hours and 59 minutes. The unit incorporates a large, easy to read LCD display with user selectable backlight and a loud audible alarm with adjustable volume to 92dB.

The ChefAlarm also includes a calibration function allowing the user to fine-tune the accuracy of the thermometer (± 2.2 °C). The unit is housed in a water resistant casing and is designed to either sit on a worktop or attach to an appliance using the magnetic pads at the rear of the instrument.

Available in three colours, each unit is supplied in a zip wallet complete with a penetration probe (810-071) and probe holder clip. See opposite page for full probe specification.



Order code	Description
810-041	ChefAlarm - white
810-044	ChefAlarm - red
810-045	ChefAlarm - blue

Specification	ChefAlarm
Range	-50 to 300 °C
Resolution	0.1 °C/°F
Accuracy	± 1 °C (-20 to 120 °C)
Battery & life	2 x 1.5 volt AAA - 5000 hours
Alarm volume	<92dB
Sensor type	Thermistor
Display	Custom LCD
Dimensions	19 x 70 x 152 mm
Weight	165 grams

DISHTEMP® DISHWASHER THERMOMETER

- Simulates maximum plate surface temperatures
- FREE traceable certificate of calibration

The DishTemp thermometer simulates a plate as it's cleaned and sanitised in a commercial dishwasher, accurately recording the maximum surface temperature at the touch of a single button, eliminating the need for costly and inaccurate test strips and stem thermometers that do not stay in place or record the surface temperature of a plate.

The instrument indicates temperature over the range of 0 to 90 °C with a resolution of 0.1 °C/°F and an accuracy of ± 0.5 °C. Incorporating a durable water-tight seal, the DishTemp thermometer is waterproof to IP66 and is supplied complete with a FREE traceable certificate of calibration.



Order code	Description
810-280	DishTemp thermometer
832-280	Stainless steel wall bracket

Specification	DishTemp
Range	0 to 90 °C
Resolution	0.1 °C/°F
Accuracy	± 0.5 °C
Battery	3 volt CR2032 lithium coin cell
Battery life	5000 hours
Display	Custom LCD
Dimensions	14 x \varnothing 127 mm
Weight	120 grams
FREE traceable certificate of calibration included	